

TERMS & CONDITIONS

1. The maps data and/or preloaded software (“Software”) in this device are licensed by third parties to Amtel Cellular Sdn Bhd (“The Company”). The Software is sub-licensed on a limited, non-exclusive, non-transferable and revocable basis for use by you solely on this device only and is not sold together with the device. If upgrades, updates or supplements to the Software are obtained, the use of such upgrades, updates or supplements is governed by these Terms and Conditions and any amendments that may accompany them and may be subject to additional payments and conditions. You must not reproduce, distribute, publish, transmit, modify, adapt, translate, display, distribute, sell, license, publicly perform, prepare derivative works based upon, or otherwise use or exploit the Software. The foregoing limited right does not give you any ownership of Software and nothing contained in this Agreement may be construed as conferring to you any licence or right to the Software under any copyright or any other intellectual property right.
2. The Software is provided by the copyright holders "AS IS" and any express or implied warranties, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are disclaimed. In no event shall the copyright owner be liable for any direct, indirect, incidental, special, exemplary, or consequential damages however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the use of the Software, even if advised of the possibility of such damage. The entire risk to the quality and performance of the Software is borne by you. This disclaimer of warranty constitutes and essential part of the licence granted to you to use the Software.
3. The trademarks, logos, and service marks (“Trademark”) displayed on this Software and device, are owned by the Company and third parties. All Trademarks not owned by the Company are the property of their respective owners, and are used with permission. Nothing contained herein may be construed as granting any right or license to use any Trademark.
4. The maps and any information stored in this device is strictly a navigation guide for reference use only. It is the sole responsibility of the User’s to use this device prudently. Information provided may change over time and you should decide the route based on the actual road conditions and traffic laws. The Company makes no representation or warranty, whether expressly or impliedly as to the accuracy, completeness, timeliness, reliability or fitness for any particular purpose of the maps stored therein.
5. The planned, shortest, quickest routes and estimated time to desired destinations are obtained from optimal route calculations based on the map database and should be used as a reference only. This device must not be used for any purpose requiring precise measurement of direction, distance, location or topography.

6. Do not fix or mount the device on such part of the windscreen that will interfere with driving of the motor vehicle or be hazardous or dangerous to the driver or occupants in the motor vehicle. User shall be responsible for his/her use of the maps stored therein and the device, and shall at all times comply with all traffic laws and regulations of the country of usage.
7. The usage of this device is dependent on the Global Positioning System (GPS) which is operated by the United States government and is solely responsible for its accuracy and maintenance. The system is subject to changes which may affect the performance and accuracy of the GPS navigator devices.
8. The use of the device is at the User's own risk. Lokatoo and the Company is not liable for any fines, penalties, damages or loss whether direct, indirect, incidental, special, exemplary, or consequential damages however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the use of the device.

CONTENTS

GETTING STARTED	5
SEARCH	
Home & Office	6
Basic Search	7
Favorites (SEARCH)	10
Telephone Number	12
History (SEARCH)	14
Address	16
POI	
POI (Near Address)	20
POI (Near GPS)	26
POI (Near Destination)	30
POI (Near Cursor)	32
POI (POI on Route)	35
Coordinate	38
MAP SCREEN MENU & FUNCTIONS	
Saving a Favorite (including Home and Office)	40
Setting Waypoint	42
Navigation Map Screen	43
Map Screen (Menu 1)	44
Map Screen (Menu 2)	45
Map Screen (Quick Menu)	45
Saving a Warning Point	46
ROUTE	
Route Information	47
Itinerary	48
Detour	49
Save Route	51
Open Route	52
View Route	53
Reverse Route	54
Cancel Route	56
Start Track Log / Stop Track Log	57
SETTING	
Language-Interface	59
Language-Voice	60
Route Option	61
Guide Option	62
Map Display	63
System Option	65
Volume	66
Safety Information	67
Map Theme	69
Quick Menu	70
GPS Information	71
Reset	73
Factory Default	74

MANAGE	
Favorites (MANAGE)	75
History (MANAGE)	77
Keyword	78
Saved Warning Point	79
Track Log	80
Version Information	81
RESTORING NAVIGATOR'S CONTENTS FROM CD ROM	82
TROUBLESHOOTING	86

GETTING STARTED

Safety Advice

- Keep off the navigator and never adjust or perform any setting to the unit while driving. Always do the necessary adjustment and setting prior to starting your journey.
- Do not fix or mount the device on such part of the windscreen that will interfere with driving or be hazardous to the driver or occupants in the vehicle.
- Always obey traffic rules. If the navigator's instructions contradict with traffic rules, the traffic rules prevail.
- Do not leave your device in the vehicle while not in use to prevent theft. Exposing your device to high temperature when not in use may cause overheating and damage the product.

Acquiring GPS satellite signal

Always acquire GPS satellite signals before using the navigator for navigation. To acquire satellite signals and to lock on your current position, please ensure that your car is not under a roof, tree or any object that might block the navigator from acquiring satellite signal.

Once navigation software is launched, the system will automatically search for satellite signals. To lock on to your current position, the navigator must lock on to at least 3 satellites. To acquire your altitude information, fourth satellite is needed.




SEARCH

Home & Office

You may retrieve your home and office location from your navigator. Tapping any of these buttons will enable the navigator to generate route to your home or office automatically.

In order to retrieve home or office, its location must be set to the navigator's memory. **Turn to page 40 to learn on how to save destination as home and office.*



Tap **Home** or **Office**.





Choose between **Recommended**, **Least Turn** and **Shortest Distance**.







Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*

Basic Search

Searching street or P.O.I (Point Of Interest).



 Spacebar	 Backspace	 Tap to empty search bar.
 Tap to display alphabetical keyboard.	 Tap to display numeric and special characters keyboard.	 Tap to confirm keyword entered.

TIPS

Enter the unique part of the street name or P.O.I for a fast and accurate search result.

For example:

JALAN PJS 7/19 to be entered as **PJ 7/19** (for street name, do not enter JALAN, LORONG, PERSIARAN, etc) and **JALAN SETIABAKTI 9** to be entered as **SETIABAKTI 9**. If you are searching for **IKANO POWER CENTRE**, just enter **IKANO**. You can search **LOT 10 SHOPPING CENTRE** by just entering **LOT 10**.

WHAT IS P.O.I?

P.O.I stands for Point Of Interest. Examples of P.O.Is are restaurants, shopping centres, petrol stations, banks and etc.

4




Screen will display results containing keywords entered for the entire selected country.

Tap **Sort by Dist** to sort the results by distance. Tap **Sort by Name** to sort the results in alphabetical order.

Use the up and down arrow buttons to scroll between pages.

5



Tap the desired destination from search result.

Then tap **Route** to go to route selection page.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

6



Choose between **Recommended, Least Turn** and **Shortest Distance**.


Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*

Favorites (SEARCH)


Retrieving a destination saved in Favorites.

1



Tap **Favorites**.

2




Screen will display list of destination records saved in Favorites.

Use the up and down arrow buttons to scroll between pages.

**To learn more about saving destination to Favorites, turn to page 40.*

3




Tap the desired destination from the list displayed.

Then tap **Route** to go to route selection page.

Alternatively, you may tap **Map** to view the map of the selected destination.

4



Choose between **Recommended, Least Turn** and **Shortest Distance**.


Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*

Telephone Number

You may search a destination via telephone number. Please note that this function is only applicable to fixed-lines telephone number of commercial premises.

1




Tap **Telephone Number**.

2




Enter the destination fixed-line telephone number using the keypad. Tap **OK** when done.

3




Screen will display results containing telephone number entered.

Use the up and down arrow buttons to scroll between pages.



4




Tap the desired destination from search result.

Then tap **Route** to go to route selection page.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

5



Choose between **Recommended, Least Turn** and **Shortest Distance**.


Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*

History (SEARCH)

Retrieving a destination saved in History.


1



The screenshot shows a menu with a power button, 'Menu', a question mark, and a globe icon. Below are four tabs: SEARCH, ROUTE, SETTING, and MANAGE. The SEARCH tab is active. It contains six icons: HOME (house), OFFICE (briefcase), Basic Search (magnifying glass), Favorites (heart on a grid), Telephone Number (phone), and a right-pointing arrow labeled '1/2'. A red arrow points to the right-pointing arrow icon.

Tap > to go to next page.

2



The screenshot shows the same menu as in step 1, but the 'History' icon (a list of horizontal lines) is now highlighted with a red arrow. The 'Basic Search' icon is no longer visible. The 'Coordinate' icon (a map) is now visible in the bottom-left position. The right-pointing arrow is labeled '2/2'.

Tap **History**.

3




The screenshot shows a list of search results under the 'History' header. The list items are: 'JLN PJS 7/19', 'JLN SULTAN (PETALING JAYA (KL/SELANGOR))', '03-21611599(RHB BANK)', '03-21611111(NIKKO (5*))', and 'EMPIRE SHOPPING GALLERY'. Each item has an up or down arrow to its right. The first item is highlighted in orange. At the bottom, there are two buttons: 'Map' and 'Route'. A page indicator '1/5' is visible between the second and third items.

Screen will display results on destination searched recently.

Use the up and down arrow buttons to scroll between pages.

4




Tap the desired destination from the list displayed.

Then tap **Route** to go to route selection page.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

5



Choose between **Recommended, Least Turn** and **Shortest Distance**.


Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*

Address

Searching street within a city, state or country.


1



The screenshot shows a main menu with a top bar containing a power icon, 'Menu', a question mark, and a globe icon. Below the bar are four tabs: 'SEARCH', 'ROUTE', 'SETTING', and 'MANAGE'. The 'SEARCH' tab is active. The menu is divided into six cells: 'HOME' (house icon), 'OFFICE' (briefcase icon), 'Basic Search' (magnifying glass icon), 'Favorites' (heart icon), 'Telephone Number' (phone icon), and a right arrow with '1/2' below it. A red arrow points to the right arrow.

Tap > to go to next page.


2



The screenshot shows the 'SEARCH' menu with the same top bar as screenshot 1. The 'SEARCH' tab is active. The menu is divided into six cells: 'History' (document icon), 'Address' (envelope icon), 'POI' (car and 'P' icon), 'Coordinate' (map icon), and a right arrow with '2/2' below it. A red arrow points to the 'Address' cell.

Tap **Address**.

3



The screenshot shows the 'Address' selection screen with a top bar containing a refresh icon, 'Address', a question mark, and a globe icon. The screen is divided into several sections: 'MALAYSIA' (country name), 'Select State' (with a close icon), 'Select City' (with a close icon), 'Select Street' (with a close icon), and 'Select Premise Lot Number'. At the bottom are 'Map' and 'Route' buttons. A red arrow points to the 'MALAYSIA' text.

Tap the country column to select the destination country.

4

The screenshot shows a mobile application interface for address selection. At the top, there is a header bar with a refresh icon, the text 'Address', a question mark, and a globe icon. Below the header, the word 'MALAYSIA' is displayed in a dark bar. Underneath, there are four rows of selection options, each with a close icon (an 'X' in a square) on the right: 'Select State', 'Select City', 'Select Street', and 'Select Premise Lot Number'. A red arrow points to the 'Select State' option. At the bottom of the screen, there are two buttons: 'Map' and 'Route'.

Tap **Select State** to enter the destination state.

5

The screenshot shows the same mobile application interface as in step 4. The word 'MALAYSIA' is still at the top. In the selection list, 'KL/SELANGOR' is now selected, and the 'Select City' option is highlighted with a red arrow. The other options ('Select State', 'Select Street', 'Select Premise Lot Number') and the 'Map' and 'Route' buttons remain the same.

Tap **Select City** to enter the destination city.

TIPS

You may choose not to select State or City or both.

- If both **State** and **City** are entered, the search result will display all relevant streets (that match the keywords entered) within the selected city.
- If **State** is entered and **City** is not entered, the search result will display all relevant streets (that match the keywords entered) within the selected state.
- If **State** is not entered and **City** is entered, the search result will display all relevant streets (that match the keywords entered) within the selected city.
- If both **State** and **City** are not entered, the search result will display all relevant streets (that match the keywords entered) within the country.

6



Tap **Select Street** to enter the destination street.


7



Enter the name of the desired destination street. Tap **OK** when done.

	Backspace		Spacebar		Tap to empty search bar
	Tap to display alphabetical keyboard.		Tap to display numeric and special characters keyboard.		Tap to confirm keyword entered.

8



Screen will display results containing keywords entered.

Use the up and down arrow buttons to scroll between pages.

Tap the desired destination from search result.


TIPS

Enter the unique part of the street name for a fast and accurate search result.

For example:

JALAN PJS 7/19 to be entered as **PJ 7/19** (for street name, do not enter JALAN, LORONG, PERSIARAN, etc) and **JALAN SETIABAKTI 9** to be entered as **SETIABAKTI 9**.

9




Address	?	🌐
MALAYSIA		
KL/SELANGOR	✕	
PETALING JAYA (KL/SELANGOR)	✕	
JLN SULTAN	✕	
Select Premise Lot Number		
Map		Route

Tap **Route** to go to route selection page.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

TIPS

Tap  to clear respective field.

10



JLN SULTAN (PETALING JAYA (KL/SELANGOR))			
	Recommended DIST 12.7km TIME 00:12		
	Least Turn DIST 13.4km TIME 00:12		
	Shortest Distance DIST 12.6km TIME 00:13		
Back	Simulation	Route Settings	Go

Choose between **Recommended, Least Turn** and **Shortest Distance**.


Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*

POI (Near Address)

Searching POI near a given street name.


1



The screenshot shows a main menu with a power button, 'Menu', a question mark, and a globe icon. Below are four tabs: 'SEARCH', 'ROUTE', 'SETTING', and 'MANAGE'. The 'SEARCH' tab is active. It contains six icons: 'HOME' (house), 'OFFICE' (briefcase), 'Basic Search' (magnifying glass), 'Favorites' (heart on a grid), 'Telephone Number' (phone handset), and a right-pointing arrow labeled '1/2'. A red arrow points to the 'Basic Search' icon.

Tap > to go to next page.


2



The screenshot shows the same main menu as in step 1, but with the 'SEARCH' tab selected. The 'SEARCH' tab now contains five icons: 'History' (list), 'Address' (envelope), 'POI' (car, heart, and 'P' in a circle), 'Coordinate' (map), and a right-pointing arrow labeled '2/2'. A red arrow points to the 'POI' icon.

Tap **POI**

3



The screenshot shows a screen titled 'POI' with a refresh button, a question mark, and a globe icon. It contains six options: 'Near Address' (magnifying glass over a map), 'Near GPS' (satellite), 'Near Destination' (flag on a road), 'Near Cursor' (magnifying glass over a checkmark), and 'POI on Route' (curved arrow around a person icon). A red arrow points to the 'Near Address' option.

Tap **Near Address**.

4

↻	Near Address	?	🌐
MALAYSIA			
Select State			✕
Select City			✕
Select Street			✕
Select Premise Lot Number			
		Search	

Tap the country column to select the destination country.

5

↻	Near Address	?	🌐
MALAYSIA			
Select State			✕
Select City			✕
Select Street			✕
Select Premise Lot Number			
		Search	

Tap **Select State** to enter the destination state.

6

↻	Near Address	?	🌐
MALAYSIA			
KL/SELANGOR			✕
Select City			✕
Select Street			✕
Select Premise Lot Number			
		Search	


Tap **Select City** to enter the destination city.

TIPS

You may choose not to select State or City or both.

- If both **State** and **City** are entered, the search result will display all relevant streets (that match the keywords entered) within the selected city.
- If **State** is entered and **City** is not entered, the search result will display all relevant streets (that match the keywords entered) within the selected state.
- If **State** is not entered and **City** is entered, the search result will display all relevant streets (that match the keywords entered) within the selected city.
- If both **State** and **City** are not entered, the search result will display all relevant streets (that match the keywords entered) within the country.

7



↻	Near Address	?	🌐
MALAYSIA			
KL/SELANGOR			✕
SUNWAY (KL/SELANGOR)			✕
Select Street			✕
Select Premise Lot Number			
		Search	







Tap **Select Street** to enter the destination street.

8



↻	Select Street	?	🌐
←	CLEAR	ABC	123
Q	W	E	R
T	Y	U	I
O	P		
A	S	D	F
G	H	J	K
L			
Z	X	C	V
B	N	M	

Enter the name of the street where your desired POI located nearby. Tap **OK** when done.

 Backspace	 Spacebar	 Tap to empty search bar
 Tap to display alphabetical keyboard.	 Tap to display numeric and special characters keyboard.	 Tap to confirm keyword entered.

9



Screen will display results containing keywords entered.

Use the up and down arrow buttons to scroll between pages.


Tap the street where your desired POI located nearby.

10




Tap **Search** to begin searching for POI nearby the road entered.

TIPS

Tap  to clear respective field.

11



Choose and tap the POI category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.


12



Choose & tap the POI sub-category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.

13




Screen will display list of result related to the POI category entered.

Tap **Sort by Dist** to sort the results by distance. Tap **Sort by Name** to sort the results in alphabetical order.

If the screen returns too many results, tap **Search to enter keyword of the desired POI to narrow down the number of results.*

14



Tap the desired destination from search result.


Then tap **Route** to go to route selection page.

Use the up and down arrow buttons to scroll between pages.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

15



Choose between **Recommended**, **Least Turn** and **Shortest Distance**.


Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*

POI (Near GPS)

Searching POI near your current location.


1



The screenshot shows a main menu with a power button, 'Menu', a question mark, and a globe icon. Below are four tabs: SEARCH, ROUTE, SETTING, and MANAGE. The SEARCH tab is active. It contains six items: HOME (house icon), OFFICE (briefcase icon), Basic Search (magnifying glass icon), Favorites (heart icon), Telephone Number (phone icon), and a right arrow with '1/2' below it. A red arrow points to the right arrow.

Tap > to go to next page.


2



The screenshot shows the same main menu, but the SEARCH tab is expanded. It contains six items: History (list icon), Address (envelope icon), POI (car and 'P' icon), Coordinate (map icon), and a right arrow with '2/2' below it. A red arrow points to the POI icon.

Tap **POI**.


3



The screenshot shows the POI search options menu. It has a refresh button, 'POI', a question mark, and a globe icon. It contains six options: Near Address (map with location pin), Near GPS (satellite), Near Destination (flag), Near Cursor (map with cursor), and POI on Route (person on route). A red arrow points to the Near GPS option.

Tap **Near GPS**.

4



Choose and tap the POI category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.

5



Choose & tap the POI sub-category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.

6




Screen will display list of result related to the POI category entered.

Tap **Sort by Dist** to sort the results by distance. Tap **Sort by Name** to sort the results in alphabetical order.

If the screen returns too many results, tap **Search to enter keyword of the desired POI to narrow down the number of results.*

7



Tap the desired destination from search result.


Then tap **Route** to go to route selection page.

Use the up and down arrow buttons to scroll between pages.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

8



Choose between **Recommended, Least Turn** and **Shortest Distance**.

Then tap **Go** to begin navigation.


**To learn more about route selection, turn to page 61.*

POI (Near Destination)

Upon setting your destination, you may search for POIs nearby your selected destination.

To use this function, a destination must be set. You may set a destination by **Basic Search** (page 7), **Telephone Number** (page 12), **Address** (page 16), **POI** (page 20) and **Coordinate** (page 38). You may also set destination by retrieve **Favorites** (page 10) and **History** (page 14) records. After the destination is set, proceed to the following;


1



The screenshot shows a main menu with a top bar containing a power icon, the word 'Menu', a question mark, and a globe icon. Below the bar are four tabs: 'SEARCH', 'ROUTE', 'SETTING', and 'MANAGE'. The 'SEARCH' tab is active. The menu is divided into a 2x3 grid of buttons. The top row contains 'HOME' (house icon), 'OFFICE' (briefcase icon), and 'Basic Search' (magnifying glass icon). The bottom row contains 'Favorites' (heart icon), 'Telephone Number' (phone icon), and a right-pointing arrow. A red arrow points to the 'Basic Search' button. The text '1/2' is at the bottom right.

Tap > to go to next page.


2



The screenshot shows the same main menu as in step 1, but with the 'SEARCH' tab selected. The grid of buttons is: 'History' (list icon), 'Address' (envelope icon), 'POI' (car and 'P' icon), 'Coordinate' (map icon), and a right-pointing arrow. A red arrow points to the 'POI' button. The text '2/2' is at the bottom right.

Tap **POI**.


3



The screenshot shows a sub-menu titled 'POI' with a top bar containing a refresh icon, the word 'POI', a question mark, and a globe icon. The menu is divided into a 2x3 grid of buttons: 'Near Address' (map with location pin), 'Near GPS' (satellite), 'Near Destination' (car on road), 'Near Cursor' (map with cursor), and 'POI on Route' (car on road with arrow). A red arrow points to the 'Near Destination' button.

Tap **Near Destination**.

4



Choose and tap the POI category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.


5



Choose & tap the POI sub-category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.

6




Screen will display list of result related to the POI category entered.

Tap **Sort by Dist** to sort the results by distance. Tap **Sort by Name** to sort the results in alphabetical order.

If the screen returns too many results, tap **Search to enter keyword of the desired POI to narrow down the number of results.*

7



Tap the desired destination from search result.


Then tap **Route** to go to route selection page.

Use the up and down arrow buttons to scroll between pages.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

8



Choose between **Recommended, Least Turn** and **Shortest Distance**.


Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*

POI (Near Cursor)


Searching POI near cursor pointed on map.

- 1




The screenshot shows a main menu with a power button, 'Menu', a question mark, and a globe icon. Below are four tabs: 'SEARCH', 'ROUTE', 'SETTING', and 'MANAGE'. The 'SEARCH' tab is active. It contains six items: 'HOME' (house icon), 'OFFICE' (briefcase icon), 'Basic Search' (magnifying glass icon), 'Favorites' (heart icon), 'Telephone Number' (phone icon), and a right arrow icon labeled '1/2'. A red arrow points to the right arrow icon.

Tap > to go to next page.
- 2



The screenshot shows the same main menu, but the 'SEARCH' tab is selected. It contains six items: 'History' (list icon), 'Address' (envelope icon), 'POI' (car and 'P' icon), 'Coordinate' (map icon), and a right arrow icon labeled '2/2'. A red arrow points to the 'POI' icon.

Tap **POI**.
- 3



The screenshot shows a 'POI' search screen with a refresh button, 'POI', a question mark, and a globe icon. It contains six options: 'Near Address' (map with address icon), 'Near GPS' (satellite icon), 'Near Destination' (flag icon), 'Near Cursor' (map with cursor icon), and 'POI on Route' (route icon). A red arrow points to the 'Near Cursor' icon.

Tap **Near Cursor**.


4



Tap to point the cursor on the map.

Then tap **OK**.

5



Choose and tap the POI category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.


6



Choose & tap the POI sub-category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.

7




Screen will display list of result related to the POI category entered. The location of these POIs is at the vicinity of the location of the cursor.

Tap **Sort by Dist** to sort the results by distance. Tap **Sort by Name** to sort the results in alphabetical order.

If the screen returns too many results, tap **Search to enter keyword of the desired POI to narrow down the number of results.*

8



Tap the desired destination from search result.

Then tap **Route** to go to route selection page.

Use the up and down arrow buttons to scroll between pages.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

9



Choose between **Recommended, Least Turn** and **Shortest Distance**.

Then tap **Go** to begin navigation.


**To learn more about route selection, turn to page 61.*

POI (POI on Route)

Upon setting your destination, you may search for POIs along the route from your start point to your destination.

To use this function, a destination must be set. You may set a destination by **Basic Search** (page 7), **Telephone Number** (page 12), **Address** (page 16), **POI** (page 20) and **Coordinate** (page 38). You may also set destination by retrieve **Favorites** (page 10) and **History** (page 14) records. After the destination is set, proceed to the following;


1



The screenshot shows a menu with a power button, 'Menu', a question mark, and a globe icon. Below are four tabs: SEARCH, ROUTE, SETTING, and MANAGE. The SEARCH tab is active. It contains six options: HOME (house icon), OFFICE (briefcase icon), Basic Search (magnifying glass icon), Favorites (heart icon), Telephone Number (phone icon), and a right arrow icon labeled '1/2'. A red arrow points to the right arrow icon.

Tap > to go to next page.


2



The screenshot shows the same menu as in step 1, but with the SETTING tab selected. It contains six options: History (list icon), Address (envelope icon), POI (car and 'P' icon), Coordinate (map icon), and a right arrow icon labeled '2/2'. A red arrow points to the POI icon.

Tap POI.


3



The screenshot shows a screen titled 'POI' with a refresh button, a question mark, and a globe icon. It contains six options: Near Address (map with location pin), Near GPS (satellite), Near Destination (checkered flag), Near Cursor (map with cursor), POI on Route (person on a path), and a right arrow icon. A red arrow points to the POI on Route icon.

Tap POI on Route.

4



Choose and tap the POI category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.

5



Choose & tap the POI sub-category from the list displayed on the screen.

Use the up and down arrow buttons to scroll between pages.

6



Screen will display list of result related to the POI category entered which are located along the route to the destination entered earlier.

Tap **Sort by Dist** to sort the results by distance. Tap **Sort by Name** to sort the results in alphabetical order.

If the screen returns too many results, tap **Search to enter keyword of the desired POI to narrow down the number of results.*

7



Tap the desired destination from search result.


Then tap **Route** to go to route selection page.

Use the up and down arrow buttons to scroll between pages.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

8



Choose between **Recommended, Least Turn** and **Shortest Distance**.


Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*

Coordinate

Searching a destination by coordinate (Longitude / Latitude).


1



The screenshot shows a main menu with a power button, 'Menu', a question mark, and a globe icon. Below are four tabs: 'SEARCH', 'ROUTE', 'SETTING', and 'MANAGE'. The 'SEARCH' tab is active. It contains six icons: 'HOME' (house), 'OFFICE' (briefcase), 'Basic Search' (magnifying glass), 'Favorites' (heart on a grid), 'Telephone Number' (phone), and a right-pointing arrow labeled '1/2'. A red arrow points to the right-pointing arrow.

Tap > to go to next page.


2



The screenshot shows the 'SEARCH' menu with the same tabs as above. The 'SEARCH' tab is active and contains six icons: 'History' (list), 'Address' (envelope), 'POI' (car and 'P'), 'Coordinate' (map with location pin), a right-pointing arrow, and '2/2'. A red arrow points to the 'Coordinate' icon.

Tap **Coordinate**

3



The screenshot shows the 'Coordinate' keypad. At the top, there is a refresh button, 'Coordinate', a question mark, and a globe icon. Below are two input fields: 'Longitude | E : ___' and 'Latitude | N :'. A '←' button is on the left, 'CLEAR' is in the middle, and 'WGS84 (Degrees)' is on the right. Below these are two rows of numbers: '1 2 3 4 5' and '6 7 8 9 0'. At the bottom, there are 'Map' and 'Route' buttons.

Enter the destination coordinate using the keypad.

	Backspace		Tap to empty search bar.
	Tap to toggle between WGS84 (Degree) and WGS84 (D-M-S) format.		

4

Tap **Route** to go to route selection page.

Alternatively, you may tap **Map** to view the map of the selected destination or to save the destination as favorite.

**To learn on how to save a favorite, turn to page 40.*

5

Choose between **Recommended, Least Turn** and **Shortest Distance**.


Then tap **Go** to begin navigation.

**To learn more about route selection, turn to page 61.*


MAP SCREEN MENU & FUNCTIONS

Saving Favorites (including Home and Office)

You can save a location searched as favorite for future retrieval. You may also save the location as Home and Office.




Upon selecting the destination from the result list, tap **Map**.



The selected location will be displayed in a map.

Tap **Save as**.



Tap the field you would like to modify.

Tap **Save** when done.

You may also tap **Home** to save the destination as Home or **Office** button to save it as Office.

Example

Save Favorites		?	🌐
Name	JLN PJS 7/19		
Tel	xxx-xxx-xxxx		
Symbol	①		
Memo	Enter Remarks		
Save		Home	
		Office	

To change the name, tap the name field.




Keyboard Input		?	🌐
ALI__			
↩	←	CLEAR	ABC
123			
OK			
Q	W	E	R
T	Y	U	I
O	P		
A	S	D	F
G	H	J	K
L			
Z	X	C	V
B	N	M	


Modify the name. Tap **OK** when done.

Setting Waypoint


Waypoint allows you to set multiple temporary stops before proceeding to your destination.



Upon selecting the destination from the result list, tap **Map**.



Tap **Waypoint** to set the selected location as waypoint.




Waypoint is set and marked with a flag. The number on the flag represents the number of the waypoint set.

You may set up to 10 waypoints for a single journey.


After setting all waypoints, set the final destination and begin driving.

Navigation Map Screen




- 1 Tap to go to Basic Search page. **To learn more about Basic Search, turn to page 7.*
- 2 Tap to save warning point. **To learn on how to save warning point, turn to page 46.*

Map Screen (Menu 1)



- 1 Tap to set the selected location as waypoint (temporary stop) before setting the final destination. **To learn more about setting waypoint, turn to page 42.*
- 2 To save a location as Favorites, Home or Office. **To learn more about saving a location as favorites, turn to page 40.*
- 3 Tap to go to route selection page once start point and destination has been entered. **To learn more about route selection, turn to page 61.*
- 4 Tap to display Quick Menu. **To learn more about Quick Menu, turn to page 70.*
- 5 Tap to display volume bar and mute option. Adjust the volume to your preferred level. Tick mute checkbox to mute the system.
- 6 Indicate the GPS signal status.



Tap to display the GPS information. **To learn more about GPS information, turn to page 71.*

- 7 Tap to display to map zoom and tilt side menu. See Map Screen (Menu 2) on page 45.
- 8 Tap to toggle between the following map orientation displays.



Map Screen (Menu 2)



- 1 Tap to display compass, GPS signal indicator and volume side menu.

Map Screen (Quick Menu)




- 1 *To learn more about customizing Quick Menu, turn to page 70.

Saving a Warning Point

You may save personalized warning points. These warning points will prompt voice alert as approaching the point. **Please note that warning point can only be saved on a road and when satellite signals are acquired.**

**To learn more about modifying saved warning point, turn to page 79.*

1



Upon reaching the location where you want to save it as warning point, tap the speed indicator.

Saving a warning point

↻	Select Warning Point Type	?	🌐
User's Safety #0			
<input type="radio"/> ? km/h	<input type="radio"/> 50 km/h	<input type="radio"/> 60 km/h	<input type="radio"/> 70 km/h
<input type="radio"/> 80 km/h	<input type="radio"/> 90 km/h	<input type="radio"/> 100 km/h	<input type="radio"/> 110 km/h
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
OK			

Tap to modify the name of warning point.

Tick to select the preferred warning point image.



Tap to save warning point.

ROUTE

Route Information

Provide information on selected route from start point to destination.



To use this function, a destination must be set. You may set a destination by **Basic Search** (page 7), **Telephone Number** (page 12), **Address** (page 16), **POI** (page 20) and **Coordinate** (page 38). You may also set destination by retrieve **Favorites** (page 10) and **History** (page 14) records. After the destination is set, proceed to the following;



Itinerary

Provide detail information on roads that will be used in navigation; from start point to destination.


To use this function, a destination must be set. You may set a destination by **Basic Search** (page 7), **Telephone Number** (page 12), **Address** (page 16), **POI** (page 20) and **Coordinate** (page 38). You may also set destination by retrieve **Favorites** (page 10) and **History** (page 14) records. After the destination is set, proceed to the following;



Detour

This function allows you to select roads to be avoided during navigation to your destination.

To use this function, a destination must be set. You may set a destination by **Basic Search** (page 7), **Telephone Number** (page 12), **Address** (page 16), **POI** (page 20) and **Coordinate** (page 38). You may also set destination by retrieve **Favorites** (page 10) and **History** (page 14) records. After the destination is set, proceed to the following;




Tap **Detour**.



Screen will display a list of road that will be taken from start point to destination.

Use the up and down arrow buttons to scroll between pages.



Select and tap to tick the road that you want to avoid.

Tap **Route** when done.

4

MONT KIARA AMAN CONDO

Hulu Kelang

Recommended
DIST 10.8km
TIME 00:12

Least Turn
DIST 15.1km
TIME 00:16

Shortest Distance
DIST 10.6km
TIME 00:13


Back Simulation Route Settings Go

A new route will be generated. The road ticked earlier will be avoided in the new route.

Save Route

After setting a route from start point to destination, you may save the route to be retrieved in the future.

To use this function, a destination must be set. You may set a destination by **Basic Search** (page 7), **Telephone Number** (page 12), **Address** (page 16), **POI** (page 20) and **Coordinate** (page 38). You may also set destination by retrieve **Favorites** (page 10) and **History** (page 14) records. After the destination is set, proceed to the following;



Tap **Save Route**.



Enter your personalized name of the route using the keyboard.

Alternatively, you may use the given default name.



Once the name is entered, tap **OK**.


The route saved can be retrieved later using **Open Route**.

To learn more about **Open Route, turn to page 52.*

Open Route

To retrieve route saved in **Save Route**. You can only retrieve a route that has been saved previously.

1



Tap **Open Route**.

A screenshot of the 'Open Route' screen. The screen displays a list of saved routes. The first item is 'P RAMLEE TO MONT KIARA'. To the right of the list are up and down arrow buttons for scrolling. At the bottom of the screen are four buttons: Open Route, Modify, Delete, and Delete All. The 'Delete All' button is highlighted.

Screen will display list of routes saved.

Use the up and down arrow buttons to scroll between pages.

Tap to retrieve the selected route. It is displayed using your preferred route setting.

Tap to modify the name of the record.

Tap to delete all records in the list.


Tap to delete all records in the list.

View Route

To view the entire route generated on the map.

To use this function, a destination must be set. You may set a destination by **Basic Search** (page 7), **Telephone Number** (page 12), **Address** (page 16), **POI** (page 20) and **Coordinate** (page 38). You may also set destination by retrieve **Favorites** (page 10) and **History** (page 14) records. After the destination is set, proceed to the following;


1



SEARCH	ROUTE	SETTING	MANAGE
Route Information	Itinerary	Detour	
Save Route	Open Route		1/2

Tap > to go to next page.


2



SEARCH	ROUTE	SETTING	MANAGE
View Route	Reverse Route	Cancel Route	
Start Track Log			2/2

Tap **View Route**.

3




Screen will display the route on the map.

Reverse Route

This function allows you to reverse the direction of the route set. For example when you set a route from point A to B, you can reverse the route to from point B to A.

To use this function, a destination must be set. You may set a destination by **Basic Search** (page 7), **Telephone Number** (page 12), **Address** (page 16), **POI** (page 20) and **Coordinate** (page 38). You may also set destination by retrieve **Favorites** (page 10) and **History** (page 14) records. After the destination is set, proceed to the following;


1



SEARCH	ROUTE	SETTING	MANAGE
Route Information	Itinerary	Detour	
Save Route	Open Route		1/2

Tap > to go to next page.


2



SEARCH	ROUTE	SETTING	MANAGE
View Route	Reverse Route	Cancel Route	
Start Track Log			2/2

Tap **Reverse Route**.

3



Start point and destination will be swapped.
Do you want to proceed?

Yes No

Select **Yes** to proceed or **No** to cancel.

4



Choose between **Recommended, Least Turn** and **Shortest Distance**.

Then tap **Go** to begin navigation.


**To learn more about route selection, turn to page 61.*

Cancel Route

To cancel route set.

To use this function, a destination must be set. You may set a destination by **Basic Search** (page 7), **Telephone Number** (page 12), **Address** (page 16), **POI** (page 20) and **Coordinate** (page 38). You may also set destination by retrieve **Favorites** (page 10) and **History** (page 14) records. After the destination is set, proceed to the following;


1



Tap > to go to next page.

The screenshot shows a menu with a power button, 'Menu', a question mark, and a globe icon. Below are four tabs: SEARCH, ROUTE, SETTING, and MANAGE. The ROUTE tab is active. The menu items are: Route Information (with a circular arrow icon), Itinerary (with a suitcase icon), Detour (with an upward arrow and a box icon), Save Route (with a document and arrow icon), Open Route (with a document and arrow icon), and a right arrow (with '1/2' below it). A red arrow points to the right arrow.


2



Tap **Cancel Route**.

The screenshot shows the same menu as above, but with different options: View Route (with a magnifying glass and circular arrow icon), Reverse Route (with a flag and circular arrow icon), Cancel Route (with a road sign and arrow icon), Start Track Log (with a track log icon), and a right arrow (with '2/2' below it). A red arrow points to the Cancel Route option.

3



Select **Yes** to proceed or **No** to cancel.


The screenshot shows a dark dialog box with a question mark icon at the top. The text inside asks 'Would you like to cancel the route?'. At the bottom, there are two buttons: 'Yes' and 'No'. A red arrow points to the 'Yes' button.

Start Track Log / Stop Track Log

This function allows you to record the track that you had taken for future retrieval. Once activated, the system will record your actual car position and movement on the road.

Your navigator should acquire satellite signal prior activating this function.


1



The screenshot shows the 'ROUTE' menu with options: Route Information, Itinerary, Detour, Save Route, Open Route, and a right arrow labeled '1/2'. A red arrow points to the right arrow.

Tap > to go to next page.

2



The screenshot shows the 'ROUTE' menu with options: View Route, Reverse Route, Cancel Route, Start Track Log, and a right arrow labeled '2/2'. A red arrow points to the 'Start Track Log' option.

Tap **Start Track Log**.

3




The screenshot shows a keyboard input screen with the text 'track_20421203080252__' and a keyboard with an 'OK' button.

Enter your personalized name of the route using the keyboard.

Alternatively, you may use the given default name.

Once the name is entered, tap **OK**.

4



To stop track log, tap **Now Logging**.

The route saved can be retrieved later using **Track Log** under **MANAGE** tab.

To retrieve saved **Track Log, turn to page 80.*

SETTING

Language-Interface


Changing the language of the interface.

1



Tap **Language-Interface**.

2



Select and tap the preferred language from the list.


Then tap **OK**.

Language-Voice

Changing the language of the voice.



Tap **Language-Voice**.




Select and tap the preferred language from the list.

Then tap **OK**.

Route Option


Changing the setting of route option method and road type.

1



Tap **Route Option**.

2



Select the preferred route method and road type. (You may select more than 1 road type)

Then tap **OK**.

Method

Recommended	System will consider various factors such as road class, speed limit, distance and number of turning to construct the best route to destination.
Least Turn	System will generate route with minimal number of turning.
Shortest Distance	System will generate a shortest distance route.

Road Type

Unpaved	To include unpaved road when generating route.
Highway	System will use highway whenever possible when generating route.
Tolled Road	System will use toll road whenever possible when generating route.

Guide Option


Changing the setting of auto zoom type, route line colour, auto GPS position and guide display.

1



Tap **Guide Option**.

2



Select the preferred setting.

Then tap **OK**.

Auto Zoom Type

Speed: Zoom level is automatically determined by travelling speed.

Distance: Zoom level is automatically determined by distance prior to next turning.

Not Use: Disabling Auto Zoom.

Route Line Colour

Set colour of route to destination.

Auto GPS Position

Set the time taken for the system to automatically move map to current position upon acquiring GPS signals.

Guide Display

Normal: Set visual display to map mode.


Turn by Turn: Set visual display to turn by turn mode.

Map Display

Changing the Day/Night mode, 3D building, car icon type and to select which POI icons to appear on the map.



Tap **Map Display**.



Select the preferred setting.

Then tap **OK**.


Day/Night Mode

Day: Set the map to day mode irrespective to the actual time.

Night: Set the map to night mode irrespective to the actual time.

User: User able to customize the day and night mode switching time.

If User is selected, tap **19:30 ~ 06:30** to set the start and end time for night mode.



Set the start and end time for night mode. Tap **OK** when done.

Auto: To use system predefined day and night mode switching time.

3D Building

Select **Yes** to enable the map to display 3D building and **No** to disable it.



3D Building enabled



3D Building disabled

Set the map display to 3D mode to get the best viewing result of 3D building.

To learn more about **map in 3D mode, turn to page 45.*

Car Icon

Tap to select preferred car icon to be used in the map.




Select your preferred car type.

Then tap **OK**.

POI

Tap to customise which POI categories to be displayed on the map.




Tick to select your preferred POI categories to be displayed on the map.

Tap **OK** when done.

System Option


Changing font size in map screen and keyboard type.

1




Tap > to go to next page.

2



Tap **System Option**.

3



Select the preferred setting.

Then tap **OK**.

Font

To select the font size in map screen. Tap the arrow buttons to toggle between small, medium and large font size.


Keyboard Type

To select between ABC or QWERTY keyboard type.

Volume


Adjusting the volume and mute option.

1




Tap > to go to next page.

2



Tap **Volume**.

3



Select the preferred setting.

Then tap **OK**.

Mute

Select **Yes** to mute the system and **No** to cancel.


Volume

Tap the arrow buttons to adjust the volume. Tap **Test** to hear the selected volume level.

Safety Information

Changing voice prompt setting for speed camera, speed limit and saved warning point.

1



Menu


SEARCH ROUTE SETTING MANAGE

Language—Interface Language—Voice Route Option

Guide Option Map Display 1/3

Tap > to go to next page.

2



Menu


SEARCH ROUTE SETTING MANAGE

System Option Volume Safety Information

Map Theme Quick Menu 2/3

Tap **Safety Information**.

3



Safety Information

Speed Camera Yes No

300 m 700 m 1 km

Speed Limit Highways No 110 km/h

Normal Roads 80 km/h

Prompt Saved Warning Point Yes No

OK Default

Select the preferred setting.

Then tap **OK**.

Speed Camera

Select **Yes** to enable the system to provide voice prompt whenever the car is approaching a speed camera area. Select **No** to disable.



Once the speed camera setting is enabled, you may set the distance for the system to prompt ahead of the speed camera. The distances available are between 300m, 700 and 1km.

**This feature is dependant on the availability of speed camera data.*

Speed Limit

Select Yes to enable and No to disable speed limit warning.



The system allow you to set your preferred the speed limit. You may set different speed limit for highways and normal roads. Once the speed limit is set, the system will alert you whenever you drive above the speed limit set.


Prompt Saved Warning Point

Select **Yes** to enable the system to provide voice prompt upon approaching a warning point saved by this user. Select **No** to disable.


**To learn on how to save a warning point, please turn to page 46.*

Map Theme


Changing the map colour.



Tap > to go to next page.



Tap **Map Theme**.



Tap the preferred map theme. Then tap **OK**.


You may tap **Preview** to preview the map colour before selecting it.

Quick Menu

This function allows you to access 5 most often used menu items from the map screen.

**To learn more about accessing Quick Menu, turn to page 45.*


1



SEARCH	ROUTE	SETTING	MANAGE
Language—Interface	Language—Voice	Route Option	
Guide Option	Map Display	1/3	

Tap > to go to next page.


2



SEARCH	ROUTE	SETTING	MANAGE
System Option	Volume	Safety Information	
Map Theme	Quick Menu	2/3	

Tap **Quick Menu**.

3



<input type="checkbox"/> Address	⤴	
<input checked="" type="checkbox"/> Favorites	⤴	
<input type="checkbox"/> Coordinate	4 / 20	
<input checked="" type="checkbox"/> POI	⤵	
<input type="checkbox"/> Telephone Number	⤵	
OK	5 / 5	Default

Tick to select your preferred (used most often) menu item from the list. (You must select 5 items.)


Use the up and down arrow buttons to scroll between pages.

Tap **OK** when done.

GPS Information


This page display all GPS signals related information such as latitude, longitude, altitude and number of satellites acquired.

1




Tap > twice to go to third page (3/3).

2



Tap **GPS Information**.

3



Screen will display the position of GPS satellites, latitude, longitude, altitude, satellite count and HDOP bars.

Red dot

GPS signals acquired and their levels of precision are low.

Yellow dot

GPS signals acquired and their levels of precision are low

Blue dot

GPS signals acquired and their levels of precision are low.

HDOP

Horizontal Dilution of Precision. High number of HDOP bars indicates high level of precision.

Latitude

Latitude value of current coordinate displayed in WGS84 format.

Longitude

Longitude value of current coordinate displayed in WGS84 format.

Altitude

Altitude value of current position.


Satellite Count

Number of satellites acquired.


Reset

Performing this function will reset all setting to default value. Users' data such as history, favorites and track log will not be deleted.


- 1



Tap > twice to go to third page (3/3).
- 2



Tap **Reset**.
- 3




Tap **Yes** to proceed. The software will exit; you will need to re-launch the software.

Tap **No** to cancel.

Factory Default


Factory default will reset all settings to default value and all users' data such as history, favorites and track log will be emptied.

1




Tap > twice to go to third page (3/3).

2



Tap **Factory Default**.

3




Tap **Yes** to proceed. The software will exit; you will need to re-launch the software.

Tap **No** to cancel.


MANAGE

Favorites (MANAGE)

Managing records saved in Favorites. You may delete or modify the name, telephone number, icon and memo of the records.




Tap **Favorites**.



Screen will display list of destination records saved in Favorites.

Use the up and down arrow buttons to scroll between pages.

**To learn more about saving destination to Favorites, turn to page 40.*



Tap to highlight the favorite record you would like to modify.

Then tap **Modify**.

Tap **Delete** to delete the selected record or **Delete All** to delete all records.

4


Modify Favorites		?	⌚
Name	SL TENG		
Tel	012-3456789		
Symbol			
Memo	Enter Remarks		
Modify		Home	Office

Tap the field you would like to modify.

Tap **Modify** when done.



You may also tap **Home** to save the record as Home or **Office** button to save it as Office.

Example

Modify Favorites		?	⌚
Name	SL TENG		
Tel	012-3456789		
Symbol			
Memo	Enter Remarks		
Modify		Home	Office

To change the telephone number, tap the telephone number field.



Keyboard Input		?	⌚
012-3456789__			
		CLEAR	ABC
1	2	3	4
5	6	7	8
9	0	\$	&
'	()	*	+
,	-	.	/
;	?		
[]	\	_
'	!	#	@
=			


Modify the telephone number.

Tap **OK** when done.

History (MANAGE)

Managing records on destination searched recently. You may delete or save the record in Favorites.

1



Tap **History**.


2



Screen will display results on destination searched recently.

Use the up and down arrow buttons to scroll between pages.

3




Tap to highlight the history record you would like to modify.

Then tap **Delete** to delete the selected record or **Delete All** to delete all records. Tap **Save** to save the record as Favorites.


**To learn more about saving destination to Favorites, turn to page 40.*

Keyword

This page display all keyword entered during searches for destination. You may delete any unwanted records here.



Tap **Keyword**.



Screen will display results on the keywords entered during searches.

Use the up and down arrow buttons to scroll between pages.


Tap to highlight the record you want to delete then tap **Delete**.

You may tap **Delete All** to delete all records.


Saved Warning Point

Managing user saved warning point.

**To learn on how to save a warning point, turn to page 46.*



Tap **Saved Warning Point**.




Screen will display list of warning point saved.

Use the up and down arrow buttons to scroll between pages.

Tap to highlight the record you want to delete then tap **Delete** or tap **Delete All** to delete all records.

Tap **Map** to view the location of the warning point saved on a map.


Tap **Modify** to modify the selected record.




Track Log

Managing track log saved. You may retrieve and view the track saved, delete or modify the track name.

**To learn on how to track a route, turn to page 57.*



Tap **Track Log**.



Screen will display list of track saved.

Use the up and down arrow buttons to scroll between pages.

Tap **View Track Log** to view the route tracked.

To delete a record, tap to highlight the record you want to delete then tap **Delete** or tap **Delete All** to delete all records.

Tap **Modify** to modify the name of the record.




Modify the record name.

Tap **OK** when done.

Version Information

This page will display software and map version. Terms & Conditions of the usage of the software can also be obtained here.

1



Tap **Version Information**

2



Tap **Version** to view the software and map version.

Tap **Terms & Conditions** to view the complete software terms & conditions.

RESTORING NAVIGATOR'S CONTENTS FROM CD ROM

If your navigator experiencing irregularity in operation or is infected by viruses, please format the storage of your navigator and restore its contents from the CD ROM provided.

1. Format the navigator's internal flash memory.

IMPORTANT

Formatting the navigator's internal flash memory will wipe out all files stored in the memory. Please backup all important files before formatting it.

For model **A903 (i)** only.

1. Switch on the navigator.
2. Tap "**Setting**", "**Sys Info**" then "**Format ResidentFlash**".



3. Tap "**Yes**" to format the navigator's internal flash memory.



4. Connect it to your computer using USB cable. Once connected, the following screen will appear. Click **A** to gain access to the navigator's storage drives.




For model **A1000 (HD)** or **B1000 (HD)** only.

1. Switch on the navigator and connect it to your computer using USB cable.
2. Once connected, the following screen will appear. Click **A** to gain access to the navigator's storage drives.




A1000 (HD) model




B1000 model


3. Double click **"My Computer"**. Right click the navigator's internal flash memory and select **"Format..."** as shown below.




4. Click **"Start"** to format the flash memory.




2. Insert the CD-ROM to the CD drive and double click "**My Computer**". Then, access the CD-ROM by double clicking its icon.
3. Double click the folder "**A903(i)**" or "**A1000(HD)**" or "**B1000(HD)**".



4. Highlight all the contents in the folder. Right click and select "Copy" from the menu.




5. Double click "My Computer". Right click the navigator's internal flash memory and select "Paste" to copy the contents to the flash memory from the CD.



5. Once the copying process is done, remove the CD-ROM from the drive and disconnect the USB cable from the navigator. To disconnect the USB cable, click "Safely Remove Hardware" icon and select "Safely remove USB Mass Storage Device – Drives(X: , X:)" as shown below.



6. Click "Navigation" at the navigator and the following screen will appear.



10. Call 1-800-88-0308 to request for activation code.

TROUBLESHOOTING

- **Software stops responding**
Push reset button at the back of the navigator and re-launch the navigation software.
- **My search is returning too many results**
Try performing a search by entering unique part of the keyword, for example *IKANO* for Ikano Power Centre.
- **The location shown in the navigator does not reflect my true current location.**
Check if the navigator is lock on to GPS satellite.
- **Voice guidance is not audible when navigating.**
Check the volume control of the navigator.
- **The navigation software cannot be launched.**
Check the navigator's storage for viruses. If the storage is infected by viruses, format it and copy the software from the CD provided.

For the latest version of this manual, please
visit www.lokatoo.com

Amtel Cellular Sdn Bhd (278151-D)
No 5, Jalan PJS 7/19, Bandar Sunway,
46150 Petaling Jaya, Selangor D.E., Malaysia.
Tel: 03-5632 6788 Fax: 03-5632 5678
E-mail: customerservice@lokatoo.com
Customer Service Hotline: 1 800 88 0308