

TERMS & CONDITIONS

1. The maps data and/or preloaded software (“Software”) in this device are licensed by third parties to Amtel Cellular Sdn Bhd (“The Company”). The Software is sub-licensed on a limited, non-exclusive, non-transferable and revocable basis for use by you solely on this device only and is not sold together with the device. If upgrades, updates or supplements to the Software are obtained, the use of such upgrades, updates or supplements is governed by these Terms and Conditions and any amendments that may accompany them and may be subject to additional payments and conditions. You must not reproduce, distribute, publish, transmit, modify, adapt, translate, display, distribute, sell, license, publicly perform, prepare derivative works based upon, or otherwise use or exploit the Software. The foregoing limited right does not give you any ownership of Software and nothing contained in this Agreement may be construed as conferring to you any licence or right to the Software under any copyright or any other intellectual property right.
2. The Software is provided by the copyright holders "AS IS" and any express or implied warranties, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are disclaimed. In no event shall the copyright owner be liable for any direct, indirect, incidental, special, exemplary, or consequential damages however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the use of the Software, even if advised of the possibility of such damage. The entire risk to the quality and performance of the Software is borne by you. This disclaimer of warranty constitutes and essential part of the licence granted to you to use the Software.
3. The trademarks, logos, and service marks (“Trademark”) displayed on this Software and device, are owned by the Company and third parties. All Trademarks not owned by the Company are the property of their respective owners, and are used with permission. Nothing contained herein may be construed as granting any right or license to use any Trademark.
4. The maps and any information stored in this device is strictly a navigation guide for reference use only. It is the sole responsibility of the User’s to use this device prudently. Information provided may change over time and you should decide the route based on the actual road conditions and traffic laws. The Company makes no representation or warranty, whether expressly or impliedly as to the accuracy, completeness, timeliness, reliability or fitness for any particular purpose of the maps stored therein.
5. The planned, shortest, quickest routes and estimated time to desired destinations are obtained from optimal route calculations based on the map database and should be used as a reference only. This device must not be used for any purpose requiring precise measurement of direction, distance, location or topography.

6. Do not fix or mount the device on such part of the windscreen that will interfere with driving of the motor vehicle or be hazardous or dangerous to the driver or occupants in the motor vehicle. User shall be responsible for his/her use of the maps stored therein and the device, and shall at all times comply with all traffic laws and regulations of the country of usage.
7. The usage of this device is dependent on the Global Positioning System (GPS) which is operated by the United States government and is solely responsible for its accuracy and maintenance. The system is subject to changes which may affect the performance and accuracy of the GPS navigator devices.
8. The use of the device is at the User's own risk. Lokatoo and the Company is not liable for any fines, penalties, damages or loss whether direct, indirect, incidental, special, exemplary, or consequential damages however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the use of the device.

CONTENTS

BEFORE USING YOUR LOKATOO GPS NAVIGATOR	
Safety Advice	5
GETTING STARTED	
Acquiring GPS satellite signal	5
Menu	6
Navigation Map Screen Description	7
To select Car Icon color	8
To allow map to display buildings in 3D (3D Buildings)	9
To toggle between Day and Night mode	10
To toggle between 2D and 3D mode	11
To customize Map Color	12
To toggle Auto Zoom	13
To enable or disable POI Label display	14
Shortcut Buttons	15
SEARCH	
To change state	16
To search a road or P.O.I (Search All)	17
To search by P.O.I category (Category Search)	20
To retrieve a destination saved in History	22
To retrieve a destination saved in Favorites	23
To search a location by coordinates (Long/Lat Search)	24
To retrieve Home	25
To retrieve Office	26
To search Nearby POIs	27
To view Help page - <i>Provide quick and brief instruction on how to use the navigator.</i>	28
ROUTE SETTING	
Setting Way Points	29
To perform simulation	30
To select Route Options	34
To view Route Info	36
To view Route View	37
To Remove Route	38
To record the route taken (Record Track)	39
To view recorded route (Show Track)	40
SAVING DESTINATION	
To save a destination to Favorites	42
To delete History entry	44
To edit or delete a Favorites entry	45
To save a destination as Home	47
To save a destination as Office	49

SETTINGS	
To adjust Volume	51
To change Language	52
To customize Warning Options	53
To customize Speed Limit	54
To view GPS Signal strength	55
To customize which P.O.I icon to be displayed on the map (POI Display)	56
To view the Terms of Use	58
To restore to Factory Settings	59
To view About Us page	60
RESTORING SD CARD CONTENTS FROM CD ROM	61
TROUBLESHOOTING	65

BEFORE USING YOUR LOKATOO GPS NAVIGATOR

Safety Advice

- Keep off the navigator and never adjust or perform any setting to the unit while driving. Always do the necessary adjustment and setting prior to starting your journey.
- Do not fix or mount the device on such part of the windscreen that will interfere with driving or be hazardous to the driver or occupants in the vehicle.
- Always obey traffic rules. If the navigator's instructions contradict with traffic rules, the traffic rules shall prevail.
- Do not leave your device in the vehicle while not in use to prevent theft. Exposing your device to high temperature when not in use may cause overheating and damage the product.

GETTING STARTED

Acquiring GPS satellite signal

Always acquire the GPS satellite signal before using the navigator for navigation. To acquire the signal and to lock on your current position, please ensure that your car is not under a roof, tree or any object that might block the navigator from acquiring satellite signal.


Once you have launched the navigation software, the system will automatically search for satellite signal. To lock on to your current position, the navigator will need to lock on to at least 3 satellites. To acquire your altitude information, the fourth satellite is needed. The figure at the top right of the map screen indicates the number of satellite captured.



Menu



Navigation Map Screen Description



NOTES

- 1 When tapped, the estimated time of arrival will toggle between the estimated remaining time of arrival and estimated clock time of arrival.
- 2 When tapped, the map screen will be zoomed in for more detailed view.
- 3 When tapped, the map screen will zoomed out for bigger coverage view.
- 4 When tapped, the map will display your current position (or your last position if no satellite captured).
- 5 This figure indicates the number of satellites being locked on. When tapped, screen will display GPS signal page. Refer page 55 for details.
- 6 When tapped, the icon will toggle between the 3 icons as below.



2D map. The map will rotate and the car will always point upward. This setting is recommended for navigation.



3D map. The map will rotate and the car will always point upward.



2D map. The system will keep the upward direction to North; the car orientation will change accordingly to this direction.

To select Car Icon color

1 →



From **Settings**, tap **Theme Settings**.



Tap **Car Icon**.



Tap to check the desired car icon color. The selected car icon color will be used in the map during navigation.

LEGEND



Go back to previous page.



View map.



Jump to main menu page.

To allow map to display buildings in 3D (3D Buildings)

1 Menu → Settings



From **Settings**, tap **Theme Settings**.



Tap **3D Buildings** to toggle between displaying buildings in 3D and displaying buildings with P.O.I icons.

NOTES

The map needs to be switched to 3D mode in order for it to be able to display 3D building. Please refer to page 11 to learn how to switch the map to 3D mode.




3D Buildings is activated.



2D Buildings is activated.

To toggle between Day and Night mode

1 →



From **Settings**, tap **Theme Settings**.



Tap to toggle between **Day** or **Night** mode.

NOTES

Below are the visual illustrations when Day or Night modes are selected.



Day mode

Night mode

In the event when no selection is made, the navigator will switch to Day mode at 7.00 am and to night mode at 7.00pm automatically.

To toggle between 2D and 3D mode

1 Menu → Settings




From **Settings**, tap **Theme Settings**.



Tap to toggle between 2D and 3D mode.

NOTES

Below are the visual illustrations when 3D or 2D map is selected.



3D

2D

To customize Map Color

1 Menu → Settings



From **Settings**, tap **Theme Settings**.



Tap **Map Color**.



Tap to check the desired map color. The selected map color will be used to display the map.

To toggle Auto Zoom

While navigating, you can choose to allow the navigator to decide the best level of zooming of the map. When activated, the map will be zoomed in when approaching junction and it will zoom out when travelling on a long straight road.


1  → 



From **Settings**, tap **Theme Settings**.



Tap the right arrow button to go to the next page.



Tap **Auto Zoom** to toggle whether to activate or disabling auto zoom function.

NOTES





Auto Zoom is activated.



Auto zoom is disabled.

To enable or disable POI Label display

You may choose to enable or disable the display of label for POIs on map screen. If POI Label display is enabled, the name of the POI will be displayed on map screen.

1  → 



From **Settings**, tap **Theme Settings**.



Tap the right arrow button to go to the next page.



Tap **POI Label** to toggle whether to enable or disable POI Label display on map screen.

NOTES




POI Label display is enabled.




POI Label display is disabled.

Shortcut Buttons









There are several selected frequently used shortcut buttons placed on the map screen for easy access.



From **View Map** screen, tap the arrow down button.




A drop down menu will appear. It is the selected shortcut button used frequently.

Icon	Description	Icon	Description
	To allow map to display buildings in 3D. Refer page 9 for details.		To customize which P.O.I icon to be displayed on the map. Refer page 56 for details.
	To select Route Options. Refer page 34 for details.		To view Route Info. Refer page 36 for details.
	To adjust Volume. Refer page 51 for details.		To toggle between Day and Night mode. Refer page 10 for details.
	To record the route that will be used. Refer page 39 for details.		To Remove Route. Refer page 38 for details.

SEARCH DESTINATION

To change state

If you are travelling to a destination in different state, you will need to change the state in the navigator to your destination state before performing search function.



From **Where To**, tap **Change State**.



Tap the desired state from the list and tap **OK**.

Tap the right arrow button to view the next page and left arrow to go to the previous page.




The navigator will switch to the selected state. The current state will shown at bottom left of the screen

To search a road or P.O.I (Search All)

1 →



From **Where To**, tap **Direct Search**.



Tap **Next**



Tap **Spell** to enter name of the desired destination.

Alternatively, you may search the desired result by browsing the list.

Tap the right arrow button to view the next page and left arrow to go to the previous page.



Enter the street name or POI using the keyboard.

TIPS

Enter the unique part of the street name and P.O.I for a fast and accurate search result.

For example:

JALAN PJS 7/19 to be entered as **PJS 7/19** (the street name without JALAN, LORONG, PERSIARAN, etc) and JALAN SETIABAKTI 9 to be entered as **SETIABAKTI 9**. If you are searching for IKANO POWER CENTRE, just enter **IKANO**. You can search LOT 10 SHOPPING CENTRE by just entering LOT 10.

WHAT IS P.O.I?

P.O.I stands for Point Of Interest. Examples of P.O.Is are restaurant, shopping centre, petrol station, bank and etc.



After entering the name, tap **Spell** again to hide the keyboard.




The screen will display the results pertinent to the keywords entered.



Tap the desired destination from the search result. Tap **OK**.

Tap the right arrow button to view the next page and left arrow to go to the previous page.

9



Tap **Go** to set the location as destination and begin driving. You may save the location as Favorites for future retrieval. To learn how to save the location as **Favorites**, please turn to page 42.

TIPS

After setting your destination, you can also choose to set multiple stops (**Way Points**) before reaching your destination. To learn how to set **Way Points**, please turn page 29.

To search by P.O.I category (Category Search)

1 →



From **Where To**, tap **Category Search**.



Screen will display a list of P.O.I categories. You may select the desired category by tapping the icon.

Tap the right arrow button to view the next page and left arrow to go to the previous page.



All search result in relevant to the P.O.I category will appear. You may search the desired result by browsing the list.



Tap **OK** after selecting the desired destination. (Alternatively, tap **Spell** to enter name of the desired destination.)

Tap the right arrow button to view the next page and left arrow to go to the previous page.

6



Tap **Go** to set the location as destination and begin driving. You may save the location as Favorites for future retrieval. To learn how to save the location as **Favorites**, please turn to page 42.

To retrieve a destination saved in History

1 →



From **Where To**, tap **History**.



The screen will display all recent searches. Tap the destination that you would like the navigator to navigate. Then tap **OK**.

Tap the right arrow button to view the next page and left arrow to go to the previous page.



Tap **Go** to set the location as destination and begin driving.

To retrieve a destination saved in Favorites

1 →



From **Where To**, tap **Favorites**.



The screen will display all destination entries saved in the Favorites. You may search the desired result by browsing the list. Tap **OK** after selecting the desired destination. (Alternatively, tap **Spell** to enter name of the saved Favorite destination.)

Tap the right arrow button to view the next page and left arrow to go to the previous page.



Tap **Go** to set the location as destination and begin driving.

To search a location by coordinates (Long/Lat Search)


1 →



From **Where To**, tap **Long/Lat Search**.



Enter the **X** and **Y** value (or **E** and **N** value) using the numerical keyboard. Tap **OK**.



Tap **Go** to set the location as destination and begin driving. You may save the location as Favorites for future retrieval. To learn how to save the location as **Favorites**, please turn to page 42.

To retrieve Home

1 →



From **Where To**, tap the right arrow button to go to the next page.



Tap **Home**. The navigator will navigate you to the home location.

NOTES

In order to use retrieve **Home**, its location needs to be set to the navigator's memory. Please go to page 47 to learn how to set a location as **Home**.

To retrieve Office

1 Menu → Where to



From **Where To**, tap the right arrow button to go to the next page.



Tap **Office**. The navigator will navigate you to the office location.

NOTES


In order to use retrieve **Office**, its location needs to be set to the navigator's memory. Please go to page 49 to learn how to set a location as **Office**.

To search Nearby POIs

You may also search the closest P.O.I from your current location.




While navigating, tap anywhere on the map except the zoom in and zoom out button.



A list of menu appears at the bottom of the screen. Tap **Nearby POIs**.



Screen will display the nearby P.O.I button. Tap the desired P.O.I.



Tap the desired destination from the search result. Tap **OK**.

Tap the right arrow button to view the next page and left arrow to go to the previous page.

5



Tap **Go** to set the location as destination and begin driving. You may save the location as Favorites for future retrieval. To learn how to save the location as **Favorites**, please turn to page 42.

To view Help page

Provide quick and brief instruction on how to use the navigator.

1



From **Menu**, tap **Help**.

2



Screen will display brief instruction on how to use the navigator.

ROUTE SETTING

Setting Way Points

10



Repeat step 1 to 8 in page 17 and 18 to search the stop you would like to make. Here, do not tap **Go**, instead tap **Save**.

(Before way points can be set, the destination need to be set first)

11



A pop up window will appear. Tap **Way Points**.

12



Way Point is set. The flag number represents the number of way points set.

To set multiple way points, please repeat step 10 and 11.


13




Once finished, tap **View Map** to begin driving.

To perform simulation

Before performing simulation, the start point and destination need to be determined.



Tap anywhere on the map except the zoom in and zoom out button.



A list of menu appears at the bottom of the screen. Tap **Where To**.



From **Where To**, tap **Direct Search**.



Tap **Next**

5



Tap **Spell** to enter name of the desired destination.

Alternatively, you may search the desired result by browsing the list.

Tap the right arrow button to view the next page and left arrow to go to the previous page.

6



Enter the street name or POI using the keyboard.

TIPS

Enter the unique part of the street name and P.O.I for a fast and accurate search result.

For example:

JALAN PJS 7/19 to be entered as **PJS 7/19** (the street name without JALAN, LORONG, PERSIARAN, etc) and **JALAN SETIABAKTI 9** to be entered as **SETIABAKTI 9**. If you are searching for **IKANO POWER CENTRE**, just enter **IKANO**. You can search **LOT 10 SHOPPING CENTRE** by just entering **LOT 10**.

7



After entering the name, tap **Spell** again to hide the keyboard.

8



The screen will display the results pertinent to the keywords entered.

9



Tap the desired destination from the search result. Tap **OK**.


Tap the right arrow button to view the next page and left arrow to go to the previous page.

10




Tap **View Map**.

11



Tap **Start Point** to mark the location as starting point. Then repeat step 2 to step 10. Mark the destination by tapping **Destination**.

12




Tap the arrow button to start simulation.

To select Route Options

You can select your preferred route to use to reach your destination. There are 3 options to choose from; **Recommended Route**, **Min Distance** and **No Highway**.

Recommended Route	The navigator will consider all classes of roads and calculate the shortest time needed to construct the best route to your desired destination.
Min Distance	The navigator will consider all classes of roads and calculate the shortest distance by KM to construct the best route to your desired destination.
No Highway	The navigator will choose other classes of routes except highway to construct the best route to your desired destination.

1 Menu → Settings



From **Settings**, tap **System Settings**.



Tap **Route Options**.

4



Select and tap your desired route.

To view Route Info

Route Info displays the list of the roads that will be used in navigation; from starting point to destination. Please note that the **Route Info** can only be viewed after the destination has been set.


1 →



From **Settings**, tap **Route**.



Tap **Route Info**.



Route Info list will be displayed begin with starting point until the destination.

Tap the down arrow button to go to next page and up arrow button to go to previous page.

To view Route View

Route View displays the entire journey route on the map; from starting point to destination. Please note that the **Route View** can only be viewed after the destination has been set.

1 Menu → Settings



From **Settings**, tap **Route**.



Tap **Route View**.



Screen will display the overall route from starting point to destination.

To Remove Route

You can cancel a destination set earlier by removing the route set. To remove a route, perform the following. Please note that the **Remove Route** button can only be tapped if the destination has been set.

1 →



From **Settings**, tap **Route**.



Tap **Remove Route**.



After **Remove Route** is tapped, the navigator will remove the destination set earlier from its memory.

(Please note that Route Info and Route View buttons are also be deactivated, indicating that there's no destination being set)

To record the route taken (Record Track)

The navigator allows you to record the route taken of a journey on the map.

1 →



From **Settings**, tap **Route**.



Tap **Record Track**.



The recording process will start immediately.

To stop recording, tap **Stop Recording**.

To view the recorded route, please go to page 40.

To view recorded route (Show Track)

In order to view the recorded route, the recording process needs to be stopped first (**Stop Recording**).

1 Menu → Settings



From **Settings**, tap **Route**.



Tap **Show Track**.

NOTES

If **Stop Recording** is displayed instead of **Record Track**, tap it to stop the recording process before tapping **Show Track**.




4



List of recorded route will be displayed. Tap the desired entry to view and tap **OK**.


Tap the right arrow button to view the next page and left arrow to go to the previous page.

5



Tap **View Map** to view the recorded track.

6



The recorded track is displayed.

NOTES

The recorded track shown on the screen is the actual travelling route. It is different from the suggested route generated by navigator when navigating.

SAVING DESTINATION

To save a destination to Favorites



After search is being performed, do not tap **Go**. Instead, tap **Save**.




A pop up window will appear. Tap **Favorites**.



Enter your preferred name to the destination using the keyboard. Once done, tap **OK**.



The location saved is marked with .

TIPS


You may also save a location as **Favorites** upon reaching a particular location.

1




Tap the location you want to save as **Favorites** in the map.

2



Tap **Set as** from the menu shown.

3



Tap **Favorites**. Then enter your preferred name to the destination using the keyboard.

To delete History entry

1 →



From **Where To**, tap **History**.




The screen will display all recent searches.

Tap the right arrow button to view the next page and left arrow to go to the previous page.



Tap the destination you would like to delete. Then tap **Delete**.



Tap **Delete** to delete the selected entry or **Delete All** to delete all entries.

To edit or delete a Favorites entry


1 →



From **Where To**, tap **Favorites**.




The screen will display all destination entries saved in the Favorites. You may search the desired result by browsing the list.



Tap the entry you want to edit from the search result. Tap **Edit**.

Tap the right arrow button to view the next page and left arrow to go to the previous page.



A pop up window will appear. Tap **Edit**.

(You may choose to delete the selected entry by tapping **Delete** or **Delete All** to delete all entries.)

6



Edit the entry's name using the keyboard. Tap **OK** twice when done.

To save a destination as Home



After search is being performed, do not tap **Go**. Instead, tap **Save**.



A pop up window will appear. Tap **Home**.



Tap **Yes** to confirm setting the location as **Home**.

TIPS

You may also set a location as **Home** upon reaching a particular location.

1



Tap the location you want to set as **Home** in the map.

2




Tap **Set as** from the menu shown.

3



Tap **Home**.

4



Tap **Yes** to confirm setting the location as **Home**.

To save a destination as Office



After search is being performed, do not tap **Go**. Instead, tap **Save**.



A pop up window will appear. Tap **Office**.



Tap **Yes** to confirm setting the location as **Office**.

TIPS

You may also set a location as **Office** upon reaching a particular location.

1



Tap the location you want to set as **Office** in the map.

2




Tap **Set as** from the menu shown.

3



Tap **Office**.


4



Tap **Yes** to confirm setting the location as **Office**.

SETTINGS

To adjust Volume





From **Settings**, tap **System Settings**.



Tap **Volume**.



Tap  to decrease and  to increase the volume.

Check **Tapping Sound** to allow the navigator to generate tapping sound whenever an icon is tapped.

To change Language

When a particular language is selected, the voice instruction and menu interface will change to the selected language. There are 3 languages to select from; **English**, **Bahasa Malaysia** and **Chinese**.

1

Menu

 →


Settings



From **Settings**, tap **System Settings**.



Tap **Language**.



Tap the desired language.

To customize Warning Options

You may customize the types of warning to be activated in the navigator. There are 3 different types of warning; **Speed Warnings***, **Camera Warnings*** and **Toll Booth Reminder**.

Speed Warnings	To remind on speed limit *Not available in Malaysia
Camera Warnings	To remind on monitored area *Not available in Malaysia
Toll Booth Reminder	To remind when approaching a toll

1 →





From **Settings**, tap **System Settings**.



Tap **Warning Options**.



Button  indicate that the option is turned on while  indicate that the option is turned off.

Tap the button to toggle between on and off.

* Not available in Malaysia

To customize Speed Limit

You may set the speed limit in the navigator. When the speed limit is set, the navigator will alert whenever the car is drive above the preset speed limit. There are 2 types of road which you can set its speed limit; **Normal Road** and **Highway**.


1 →





From **Settings**, tap **System Settings**.



Tap **Speed Limit**.



Tap  to decrease and  to increase the speed limit.

NOTES

The speed limit ranges from 30km/h to 70km/h for normal road and 70km/h to 120km/h for highway.

To view GPS Signal strength


1 Menu → Settings



From **Settings**, tap **Theme Settings**.



Tap **GPS Signal**.



Screen will display the GPS signal page. The longitude, latitude, current time, height and vehicle speed will also be displayed.

To customize which P.O.I icon to be displayed on the map (POI Display)


1 Menu → Settings



From **Settings**, tap **Theme Settings**.



Tap the right arrow button to go to the next page.



Tap **POI Display**.

5




Tap to check the P.O.I category icon that you want to appear on the screen and uncheck the P.O.I icon you do not want to appear on the screen.

TIPS


To display all P.O.I categories, check **All**. If you do not wish to see any P.O.I icon displayed on the map, check **Cancel All**.

To view the Terms of Use

The Terms of Use of the navigator's usage are stored herein. A copy of the Terms and Use can also be found at the beginning pages of this manual.



From **Settings**, tap **Terms of Use**.



Tap the right arrow button to view the next page and left arrow to go to the previous page.

To restore to Factory Settings

1 →



Tap **Factory Settings**.



Tap **Yes** to restore to factory settings and **No** to cancel.

To view About Us page

This page will display the map, software and voice version.

1



From **Menu**, tap **About Us**.

2



Screen will display the map, software and voice version.

RESTORING SD CARD CONTENTS FROM CD ROM

If your navigator experiencing irregularity in operation or is infected by viruses, please perform a SD card restore from the CD ROM.

1. Switch on the navigator and connect it to your computer using USB cable.
2. Once connected, the following screen will appear.




A903 & A1000 model




B1000 model

Click **A** to gain access to the navigator's storage drives.

3. Alternatively, you can remove the SD card from the navigator and insert to a card reader.
4. Double click "My Computer". Right click the SD card drive and select "Format..." as shown below.




5. Under "File system", select "FAT" and click "Start" to format the SD card.




Note

Formatting the SD card will wipe out all files stored in the card. Please backup all important files before formatting it.


6. Insert the CD-ROM to the CD drive and double click "My Computer". Then, access the CD-ROM by double clicking its icon.
7. Double click the folder "A903 & A1000 Series" (or "B1000 Series")



8. Highlight all the contents in the folder. Right click and select "Copy" from the menu.




9. Double click "My Computer". Right click the SD card drive and select "Paste" to copy the contents to the SD card from the CD.



10. Once the copying process is done, remove the CD-ROM from the drive and disconnect the USB cable from the navigator and computer (or remove SD card from card reader). To disconnect the USB cable (or remove the SD card), click "Safely Remove Hardware" icon and select "Safely remove USB Mass Storage Device – Drives(X: , X:)" as shown below.



11. Click "Navigation" at the navigator and the following screen will appear.



10. Call 1-800-88-0308 to request for activation code.

TROUBLESHOOTING

- **Program stops responding when using it.**
Tap reset button at the back of the navigator and re-launch the navigation software.
- **My search is returning too many results.**
Try performing a search by entering the most unique part of the keyword, for eg. *IKANO* for *Ikano Power Centre*.
- **The location shown in the navigator does not reflect my true current location.**
Check if the navigator is lock on to GPS satellite. You will need at least 3 satellites to be locked on. Fourth satellite is needed to identify your altitude.
- **Voice guidance is not audible when navigating.**
Check the volume control of the navigator.
- **The navigation software cannot be launched.**
 1. Check the condition of the SD card. Change the SD card if it is damaged.
 2. Check the SD card for viruses. If the SD card is infected by virus, format it and copy the software from the CD provided.

For the latest version of this manual, please
visit www.lokatoo.com

Amtel Cellular Sdn Bhd (278151-D)
No 5, Jalan PJS 7/19, Bandar Sunway,
46150 Petaling Jaya, Selangor D.E., Malaysia.
Tel: 03-5632 6788 Fax: 03-5632 5678
E-mail: customerservice@lokatoo.com
Customer Service Hotline: 1 800 88 0308